


508	Main Group 33 Rear Wheel Drive	Special tools Motorcycle
-----	-----------------------------------	-----------------------------

Special wrench with counter support

For loosening and tightening of universal joint hub SW-22+24. (SW 24 is also single available) Use 88 88 6 331 650 and standard socket wrench

NOTE: Even though some part numbers are NLA they are listed for reference for those technicians / dealers who are currently using these numbers.



Area of application:	508
R60, R67, R67/2, R68, R69, R69S R50/5, R60/5, R75/5	
<hr/>	
<hr/>	
<hr/>	