Puller

For removal of the driving flange (transmission) Use 88 88 6 231 700/710

NOTE: ***Even though some part numbers are NLA they are listed for reference for those technicians / dealers who are currently using these numbers.***



501

Area of application: **501**

R50, R60, R69S