Setting tool

For the centering of the output shaft when setting the selector fork (transmission)
Use 88 88 6 232 750

NOTE: ***Even though some part numbers are NLA they are listed for reference for those technicians / dealers who are currently using these numbers.***

Area of application: **504**

R24, R25, R25/2, R25/3, R26, R27, R50, R50S, R60, R69, R69S R50/5, R60/5, R75/5